



Handy Recorder

ver. 2.0

Operation Manual



Contents

Introduction	3
Copyrights	3
Main Screen	4
Landscape mode (new in ver. 2.0)	5
Recording	6
Pausing recording	6
Adjusting the recording level	7
Setting the recording format	7
Muting the input	8
Adding recordings (landscape mode only) (new in ver. 2.0)	9
Using mid-side recording (iQ series MS mic only feature)	11
Setting mid-side monitoring	11
Playback	12
Selecting and playing files	12
Pausing playback	13
Playing files from the FILE screen	13
Adjusting the playback level	14
Repeating playback of an interval (new in ver. 2.0)	14
Editing and deleting files	15
Dividing files (landscape mode only)	15
Deleting file beginnings/ends (landscape mode only) (new in ver. 2.0)	16
Deleting files	18
Deleting all files (new in ver. 2.0)	19
Using effects	20
Effect settings	22
Enabling direct monitoring (iQ series only feature)	23
Setting the AUTO GAIN (iQ5 only feature)	24
Adjusting DIGITAL MIC GAIN	25
Using AUTO REC	26
Turning the AUTO REC function ON/OFF	27
Setting the START LEVEL	27
Turning the AUTO STOP function ON/OFF	28
Setting the STOP LEVEL	29
Sharing recorded files	30
Uploading files to SoundCloud	30
Uploading files to SoundCloud from the FILE screen	31
Sending a file by email	32
Changing the name of a shared file	33
Changing sharing settings	33
Transferring recordings to a computer	34
Updating iQ series mic firmware	35
Locking the controls	36
Other options	37
Swapping left and right input channels	37
Restoring default settings	37

Introduction

Handy Recorder is a high-performance PCM/AAC recording application that runs on iOS. Use it together with a **zoom.iQ** series stereo mic for iOS devices (hereafter, the **iQ** series) for high-quality stereo recording. In addition, you can use this app to play back and edit recorded files, to apply reverb and other effects to them and to upload them to SoundCloud. This app can also start and stop recording automatically in response to the input audio level.

Handy Recorder can be used with external mics other than the **iQ** series as well as built-in iOS device mics.


Copyrights

iPad, iPhone, iPod, and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries.

Note: All trademarks and registered trademarks in this document are for identification purposes only and are not intended to infringe on the copyrights of their respective owners.

Main Screen

When you start **Handy Recorder**, the Main Screen appears.



Mid-side file playback



Stereo width adjuster

This adjusts the stereo width of mid-side recording files during playback. (→P11)

Information display

- ① This shows whether the app is recording, playing back, stopped or paused.
- ② This shows the current playback/recording time.
- ③ This shows the input status. (→P8)
- ④ This shows the width setting. If an **iQ** series mic is connected, 90°, 120° or M-S will appear. If a different stereo mic is connected, STEREO will appear. Otherwise, MONO will appear.
- ⑤ This shows the current recording format. (→P7)
- ⑥ This shows the remaining possible recording time on the iOS device using the current format.
- ⑦ This shows the name of the file that is being recorded or played back.
- ⑧ This shows the playback levels when a file is playing back. Otherwise, it shows the current input levels.
- ⑨ This shows the waveform of the current file. It will be blank if there is no recorded file.

Controls

- ⑩ **Rotate button** Touch to switch to landscape mode.
- ⑪ **Stop button** Touch when playing back or recording to stop. Touch when stopped to move the playback position to the beginning of the file.


- ⑫ **Play button** Touch to start playing a recorded file. (→P12)
- ⑬ **Record button** Touch to start recording. (→P6)
- ⑭ **FF/REW buttons** Touch to change the current file. Hold during playback to search backward/forward. These do not function when recording or when there is no playback file.
- ⑮ **Lock slider** Lock to disable the **Handy Recorder** buttons. Unlock to enable use of the buttons. (→P35)
- ⑯ **Volume adjustment bar** Use to adjust the output volume. (This only appears when an **iQ** series mic is connected.) When it appears, the iOS device volume buttons are disabled.

Menu buttons

- ⑰ **EFFECT** Use effects on recorded files. (→P19)
- ⑱ **SHARE** Upload recorded files to SoundCloud and send them by email (→P29)
- ⑲ **FILE** Manage and edit recorded files.
- ⑳ **MENU** Access automatic recording and other settings. (→P23–28)

Waveform display

This shows the waveform of the selected file. If the file was recorded with left and right channels, the average value of the two channels will be shown. If the file was recorded in MS-RAW mode, only the mid (M) waveform will be shown. This area will be blank if there is no recorded file.



This shows the current playback position of the file playing. Slide it to a point to play back from there.

Landscape mode

New in ver. 2.0

Press the rotate button to change to landscape mode.



Indicators

- ① This shows whether the app is recording, playing back, stopped or paused.
- ② This shows the current playback/recording time.
- ③ This shows the playback levels when a file is playing back. Otherwise, it shows the current input levels.
- ④ This shows the waveform of the current file. If the file was recorded in stereo, two waveforms will be shown. The waveforms for files recorded with left and right channels will be shown with the left channel above and the right channel below. The waveforms for files recorded in MS-RAW mode will be shown with the mid (M) channel above and the side (S) channel below. Pinch out/in along the time axis to zoom in/out on the waveform.
- ⑤ This shows the current playback position of the file.
- ⑥ Drag this start locator to set the interval starting point.
- ⑦ Drag this end locator to set the interval ending point.
- ⑧ This shows how much of the entire file is being shown in the waveform display area above. Pinch out/in along the waveform time axis to zoom in/out on the file. The light blue interval is being shown above, while the dark blue parts are not being shown. The red line shows the current playback position, and the yellow lines show the starting and ending points of the selected interval.

Buttons

- ⑨ **Stop** Touch when playing back or recording to stop. Touch when stopped to move the playback position to the beginning of the file.
- ⑩ **Play** Touch to start playing a recorded file. (→P12)
- ⑪ **FF/REW** Move the playback position forward or backward one second. Hold during playback to search backward/forward. These do not function when recording or when there is no playback file.
- ⑫ **Record** Touch to start recording. (→P6)
- ⑬ **Recording mode** Touch to change the recording mode. (→P9)
- ⑭ **UNDO** Use to undo an additional recording. After a recording is added, it will appear lit. If used to undo, it will become unlit again. (→P9)
- ⑮ **Edit** Divide at the selected position or erase the selected interval. (→P15)
- ⑯ **Rotate button** Touch to switch to portrait mode.

Recording

Follow these steps to use the recording functions of the app.



1. Touch

During recording,  becomes red.

2. Touch

Recording stops.


NOTE

- By connecting headphones to an **iQ** series mic, you can listen to audio while it is recorded.
- Turn direct monitoring on to listen to audio as it is recorded without any time lag. (→P22)
- When using landscape mode, confirm that the recording mode is "New Rec" before starting a new recording.

Pausing recording



1. Touch during recording

When paused,  blinks red.


2. Touch again

Recording starts again.

Adjusting the recording level

When using an **iQ** series mic, use the MIC GAIN control on its side to adjust the recording level. When using the mic built-in to the iOS device, adjust the DIGITAL MIC GAIN. (→P24)

Setting the recording format



1. Touch **MENU**
2. Touch **REC FORMAT**
3. Select the recording format

The default setting is WAV44.1kHz.

The options are WAV44.1kHz, WAV48kHz, AAC64kbps, AAC128kbps and AAC160kbps.

WAV format	Use to record with better audio quality.
AAC format	This lowers audio quality but also reduces file sizes, conserving storage space on the iOS device.

NOTE

- When using the WAV format, if the recording file size exceeds 2 GB, a new recording will be created automatically. When the new file is created, recording will continue without any gap. When using the AAC format, if the recording file size exceeds 400 MB, a new file will be created in the same manner.
- The WAV48kHz option is enabled when an **iQ** series mic is connected.
- If the WAV48kHz setting had been selected previously but the app is opened before connecting an **iQ** series mic, it will automatically be switched to WAV44.1kHz. Check the recording format before recording.

Muting the input

Follow these procedures to mute the input.




1. Touch

This mutes the input.

2. Touch

This unmutes the input.

You can start recording to an already recorded file from any point you like. Additional recordings can overwrite, overdub or be inserted into already recorded files.



1. Select a file on the Main Screen or the FILE screen (→P12)

2. Touch 

The screen switches to landscape mode.


3. Check the recording format

If you want to record in standard stereo, confirm that the LR indicator appears between the time and the level meters.

If you want to record in mid-side mode, confirm that the MS indicator appears between the time and the level meters. (→P11)

NOTE

- Do not add MS recordings to already recorded stereo files or stereo recordings to already recorded MS files.
- Do not add stereo LR or MS recordings to already recorded mono files or mono recordings to already recorded stereo LR or MS files.

4. Slide  to the point where you want to start additional recording

5. Touch **New Rec** and set the recording mode to Overwrite, Overdub or Insert

Overwrite	This replaces the original recording with the new recording.
Overdub	This combines the original recording with the new recording.
Insert	This inserts the new recording into the original recording.

NOTE

- If the recording mode is set to **New Rec**, a new file will be recorded.

6. Touch

Additional recording starts.

7. Touch

Additional recording stops. The waveform of this additional recording is shown in red.

8. Touch to undo this additional recording

This reverts the recording to the state before this additional recording was made.

NOTE

- If multiple additional recordings have been made, only the most recent additional recording can be undone.
- Additional recordings cannot be undone after they have been saved. Additional recordings are saved whenever a file is divided, trimmed or shared, a file with an effect applied is saved, a new recording file is created, a different file is selected or **Handy Recorder** is closed.
- When using the Overwrite and Overdub functions, you can set the interval of the additional recording. To set this interval, slide the start locator to the starting point and the end locator to the ending point.
When using Overwrite, the file will be overwritten until the ending point of the selected interval where additional recording will stop automatically.
When using Overdub, the file will be overwritten until the ending point of the selected interval, and then recording will automatically continue from the starting point, allowing repeated overdubbing.
- The recording format used to save an additional recording is the same as that of the originally recorded file.

Using mid-side recording iQ series MS mic only feature

This app can be used for mid-side recording. To use this function, connect an **iQ** series mic and set its stereo width switch to M-S.



1. Touch

2. Touch

Recording starts.

NOTE

- When you play a file that was recorded in mid-side mode, a stereo width adjustment control appears. Slide this to set the stereo width of the **audio during playback**.

Setting mid-side monitoring

Set the type of monitoring to use when mid-side recording.



1. Touch **MENU**

2. Touch **M-S MONITOR**

3. Touch **STEREO** or **M-S**

When set to **M-S**, the mid mic can be monitored through the left channel and the side mic through the right channel.

4. Touch **MENU**

The Main Screen reopens.

NOTE

- When direct monitoring is on, the M-S MONITOR setting has no effect on the audio heard through the **iQ** series mic. The output will be as though set to M-S.

Playback

Follow these steps to play back recorded files.

Selecting and playing files



NOTE

- The volume set with the volume control bar is stored in the **iQ** series mic itself and will be applied when the mic is used with other applications.

Slide to adjust the output volume


- Left to lower
- Right to raise

(Only appears when an **iQ** series mic is connected)

1. On the Main Screen, use ◀ / ▶ to show the file you want to play

2. Touch

Playback starts. During playback, lights green.



3. Touch

Playback stops.

NOTE

- You can change the screen to landscape mode during file playback.
- In landscape mode, you can select the playback interval.
- In landscape mode, you cannot select files.

● Pausing playback



1. During playback, touch

When paused, blinks green.


2. Touch again

Playback starts again.

NOTE

- Pausing works the same way in landscape mode. Touch .

● Playing files from the FILE screen



Scrolling up and down is possible.
The files appear in order of age, with the oldest file at the top of the list.

1. Touch **FILE**
2. Touch the file name on the **FILE** screen
The selected file is highlighted blue.
3. Touch

During playback, appears green.


Adjusting the playback level

When using an **iQ** series mic, slide the volume control.

When not using an **iQ** series mic, use the iOS device volume buttons.

Repeating playback of an interval New in ver. 2.0

You can repeat playback between two set points. These points can only be set when in landscape mode.



1. Select a file from the Main Screen or the FILE screen (→P12)

2. Touch 

The screen switches to landscape mode.

3. Slide the start locator to the starting point

This sets the starting point of the interval that will be played back repeatedly.

4. Slide the end locator to the ending point

This sets the ending point of the interval that will be played back repeatedly.

5. Touch 

Repeat playback of the set interval starts.

6. Touch 

Repeat playback stops.

NOTE

- You can even set the two points while the file is playing.


Editing and deleting files

The app can be used to divide and delete recorded files, as well as to trim (delete) their beginnings and ends.

Dividing files Landscape mode only

You can divide a recorded file into two parts. This function can only be used in landscape mode.



1. Select a file from the Main Screen or the FILE screen (→P12)
2. Touch 
The screen switches to landscape mode.
3. Slide the start or end locator to where you want to divide the file

NOTE

- You can also play a file to confirm the division point.

4. Touch 
A "Choose edit." message appears.
5. Touch "Divide at START" or "Divide at END"
A "Save as new file?" message appears.

6. Touch New, Overwrite or Cancel

A "Now Processing" message appears.

When file division completes, "Complete!" appears.

New	Create divided files and also save the original file.
Overwrite	Create divided files and delete the original file.
Cancel	Cancel division.

7. Touch OK

NOTE

- During division, do not turn off the iOS device or quit **Handy Recorder**. Doing so could cause loss of data.
- The first part of the divided file is saved with "A" added to the end of the original file name, and the second part is saved with "B" added to the end of the original name.

Deleting file beginnings/ends Landscape mode only New in ver. 2.0

You can delete (trim) unwanted beginnings and endings of files. This function can only be used in landscape mode.



1. Select a file from the Main Screen or the FILE screen (→P12)

2. Touch 

The screen switches to landscape mode.

3. Slide the start locator to the interval starting point

4. Slide the start locator to the interval ending point

5. Touch  to trim the file to the selected interval

A “Choose edit.” message appears:

6. Touch **“Trim between START and END”**

A “Save as new file?” message appears.

When trimming completes, “Complete!” appears.

7. Touch **New, Overwrite or Cancel**

A “Now Processing” message appears.


When trimming completes, “Complete!” appears.

New	Create trimmed file and also save the original file.
Overwrite	Create trimmed file and delete the original file.
Cancel	Cancel trimming.

8. Touch **OK**

Deleting files

The app can be used to delete recorded files.




1. Touch **FILE**

2. Touch 

A screen opens where you can select files to delete.

3. Touch the names of files that you want to delete

 marks appear next to the names of selected files. You can select multiple files.

4. Touch **DELETE**

A confirmation message appears:

“Delete File? This will delete the selected file(s). It cannot be undone!”

5. Touch “Delete”


The FILE Screen reappears after deletion completes.

6. Touch **FILE**

The Main Screen reopens.

Deleting all files New in ver. 2.0

You can delete all the files in the app at the same time.



1. Touch **SELECT ALL** on the file deletion selection screen

This selects all the files.

2. Touch **DELETE**

A confirmation message appears:

“Delete files? This will delete the selected files. It cannot be undone!”

3. Touch “Delete”

All the files are deleted.

Using effects

The app can be used to apply effects to recorded files.



1. Select a file from the Main Screen or the FILE screen (→P12)
2. Touch **EFFECT**
3. Touch **EQ**, **REVERB** or **MASTERING**
4. Make effect settings
For details about how to use and set each effect, see P21.

5. Touch **EFFECT** on the effect setting screen

6. Touch “Save with EFFECT/NORMALIZE”

7. On the “Save as new file?” message, touch **New**, **Overwrite** or **Cancel** to select how the file is saved

New	The original file is not changed. A new file is created with the effect applied. The new file is saved and named with the newest number.
Overwrite	The original file is overwritten with the effect applied.
Cancel	No file is created with the effect applied.

8. To optimize the file volume, touch **YES** on the “Normalize file?” message

When normalization completes, “Complete!” appears.

Touch **CANCEL** to save the file without optimizing the volume.

NOTE

- While saving a file, do not turn off the iOS device or quit **Handy Recorder**. Doing so could cause loss of data.


9. Touch **EFFECT**

The Main Screen reopens.


NOTE

- After making effect settings, you can play back the file to hear the affected audio.
- Effect settings are applied to audio playback. They are not applied to input audio.

■ **EQ** (adjust/correct sound quality)

Slide the  faders on the frequency bands (160Hz/400Hz/800Hz/3.2kHz/6.4kHz/12kHz) to adjust the sound quality.

Touch **RESET** to restore sound to its flat state (no EQ).



■ **REVERB** (add sound reverberations)

This is **OFF** by default.

Touch **ROOM**, **JAZZ CLUB**, **CONCERT HALL**, **ARENA** or **STADIUM**.



REVERB

OFF	Off
ROOM	Simulates the reverberations of a room
JAZZ CLUB	Simulates the reverberations of a jazz club
CONCERT HALL	Simulates the reverberations of a concert hall
ARENA	Simulates the reverberations of an arena
STADIUM	Simulates the reverberations of a domed stadium

■ **MASTERING** (increase impact)

This is **OFF** by default.

Touch **MAXIMIZE**, **ULTRA MAXIMIZE**, **CLEAR & POWER**, **WIDE** or **MONO**.




MASTERING

OFF	Off
MAXIMIZE	Evens the volume level with soft compression
ULTRA MAXIMIZE	Evens the volume level with strong compression
CLEAR & POWER	Emphasizes mid frequencies with compression
WIDE	Emphasizes stereo elements
MONO	Centers all sound dispersed to the left or right

Enabling direct monitoring

iQ series only feature

Sound can be output directly from the mic for monitoring without any time lag.



1. Touch **MENU**
2. Touch **DIRECT MONITOR**
3. Touch **ON** or **OFF**
4. Touch **MENU**

The Main Screen reopens.

NOTE

- The direct monitoring setting has no effect when using the **iQ** series mic with any app other than **Handy Recorder**.
- When direct monitoring is on, you will be able to monitor sounds input through the mic even when a file is playing back.
- When direct monitoring is on, the **DIGITAL MIC GAIN** setting does not affect sound monitored through the **iQ** series mic. It does affect the sound recorded by **Handy Recorder**.
- When direct monitoring is on, the **M-S MONITOR** setting has no effect on the audio heard through the **iQ** series mic. The output will be as though set to M-S.

Setting the AUTO GAIN iQ5 only feature

When the **iQ5** AUTO GAIN/LIMITER switch is set to **AUTO GAIN**, the gain will be adjusted suitably in response to the input level according to the setting.



1. Touch **MENU**
2. Touch **AUTO GAIN**
3. Touch **CONCERT**, **SOLO** or **MEETING**

The default setting is **SOLO**.

CONCERT	Good for band performances, concerts and other loud situations
SOLO	Good for acoustic guitar and similar solo performances
MEETING	Good for meetings and other quiet situations

4. Touch **MENU**

The Main Screen reopens.


NOTE

- The AUTO GAIN setting made in **Handy Recorder** is stored in the **iQ5** itself and will be applied when the **iQ5** is used with other applications.

Adjusting DIGITAL MIC GAIN

Adjust the recording level to record quiet sound sources at a higher level and loud sources at a lower level.


This setting affects the built-in iOS device mic, an **iQ** series mic or any other external mic.



1. Touch **MENU**
2. Touch **DIGITAL MIC GAIN**
3. Slide ● to adjust the gain (dB)

This shows the adjusted gain value (dB)

• -∞ means input is muted



Slide to adjust the gain (dB)

- Left to lower
- Right to raise

4. Touch **MENU**
The Main Screen reopens.

Using AUTO REC

The AUTO REC function can be set to start and stop recording automatically.



1. Touch **MENU**

2. Touch **AUTO REC**

You can turn automatic recording ON/OFF and set its start level and stop conditions.

3. Touch **ON/OFF**, **START LEVEL** or **AUTO STOP**

See P26–28 for how to make each setting.


4. Touch **MENU**

The Main Screen reopens.

5. Touch 

Recording will start automatically when the input level exceeds the **START LEVEL**.

Turning the AUTO REC function ON/OFF




1. Touch ON/OFF on the AUTO REC screen

2. Touch ON or OFF

When set to ON, "AUTO" will appear on the Record button.

Setting the START LEVEL

Set the level that causes automatic recording to start.




1. Touch START LEVEL on the AUTO REC screen

2. Slide  to adjust the automatic recording start level

You can set this level between -48dB and 0dB. The default setting is -24dB.

Turning the AUTO STOP function ON/OFF

Set the number of seconds until automatic recording stops after the level goes below the set STOP LEVEL.





1. Touch **AUTO STOP** on the **AUTO REC** screen
2. Touch **ON/OFF**
3. Touch the number of seconds until automatic recording stops
4. Touch **AUTO STOP**
The **AUTO STOP** screen reopens.

Setting the STOP LEVEL

Set the level at which automatic recording stops.




1. Touch **AUTO STOP** on the **AUTO REC** screen
2. Touch **STOP LEVEL**
3. Slide  to adjust the automatic recording stop level
You can set this level between -48dB and 0dB. The default setting is -24dB.
4. Touch 
The **AUTO STOP** screen reopens.

Sharing recorded files

You can upload your recordings to the SoundCloud music sharing service and send them by email so others can listen to them.

● Uploading files to SoundCloud



1. Load the file on the Main Screen (→P12)

NOTE

- If an interval is selected, the file will be trimmed to that interval before being uploaded.

2. Touch **SHARE**

3. Touch **SoundCloud**

4. Touch **Log In**

The SoundCloud account input screen appears.

If you do not have a SoundCloud account, you can create one on the SoundCloud web site.

5. Log in to SoundCloud and touch **Upload**

An “Uploading...” message appears.

When uploading completes, a “Complete!” message appears.

NOTE

- During uploading, do not turn off the iOS device or quit **Handy Recorder**. Doing so could cause loss of data.

6. Touch **Log Out**

7. Touch **SHARE**

The Main Screen reopens.

● Uploading files to SoundCloud from the **FILE** screen



1. Select the file you want to upload on the **FILE** screen (→P13)

2. Touch

The **SHARE** screen opens. See P29 for additional steps.

Sending a file by email

You can attach a recorded file to an email and send it.



1. Touch **Email** on the SHARE screen

2. Touch

An email message with the recording attached is created.

NOTE

- If an interval is selected, the file will be trimmed to that interval before being attached to the email.
- If no email account has been set up on the device, this message appears: "No Email Account. Please set up an email account in order to send email."

3. Input the recipient (to:), subject and message, and then touch **Send**

The email message with the recording attached is sent.

NOTE

- If the attachment exceeds the maximum allowed size, this message appears: "The email could not be sent. The audio file exceeds the email attachment size limitation." (→P32)

Changing the name of a shared file



1. Touch **Rename** on the **SoundCloud/Email** screen

"Enter New File name" appears.

2. Input the file name

3. Touch **Rename**

The file name is changed.

Changing sharing settings



1. Touch **Setting** on the **SoundCloud/Email** screen

The **SETTING** screen appears.

2. Touch **SHARE TO**, **M-S >> STEREO ENCODE**, **WAV >> AAC ENCODE** or **Email Limit**

3. Change the setting

SHARE TO	Set whether the files you upload to SoundCloud are PRIVATE or PUBLIC .
M-S >> STEREO ENCODE	Set whether mid-side recording files are converted to stereo before uploading (ON/OFF). During conversion, the stereo width adjustment setting is used. (→P7)
WAV >> AAC ENCODE	Set whether WAV format files are converted to AAC format before uploading (OFF/64kbps/128kbps/160kbps).
Email Limit	Set the maximum size of files attached to email (1–25MB).


NOTE

- The **SHARE TO** setting is only for SoundCloud.
- The **Email Limit** setting is only for email.


Transferring recordings to a computer

1. Connect the iOS device to the computer and launch iTunes

2. Select the iOS device in iTunes




3. Open the Apps tab



4. Select “HandyRec.” from the Apps list in the File Sharing area at the bottom of the screen.

The recording files are shown.



5. Select the file

6. Click “Save to...”

7. Select the place where you want to save the file


The file is saved to the computer.

NOTE

- You can also drag and drop files to where you want to save them.

Updating **iQ** series mic firmware

Connect an **iQ** series mic to update its firmware to the latest versions.
This example uses an **iQ5**.



1. Touch **MENU**

2. Scroll down the **MENU**, and touch **FIRMWARE UPDATE**

If the **iQ** series mic is connected properly, the current version and the latest version will be shown.

NOTE

- If "Unsupported function." appears, the **iQ** series mic is not connected properly.

3. Touch **OK**

4. When “Update version?” appears, touch **Update**

An “Updating...” message appears.

Touch **Cancel** to stop the update.

When updating finishes, “Rebooting the iQ5... Do not disconnect the iQ5.” appears and then the Main Screen reopens automatically. (This example uses an **iQ5**. The message that appears when the update finishes will show the name of the connected **iQ** series mic.)

NOTE

- During a firmware update, do not disconnect the **iQ** series mic from the iOS device or quit **Handy Recorder**.
- When updating the firmware, use of the iOS device's phone or alarm functions could cause the update to fail and the iOS to become unstartable. When updating, always put the iOS device into Airplane Mode and turn off any alarms.
- Before starting a firmware update, confirm that the iOS device has enough remaining battery power.

Locking the controls

You can disable the **Handy Recorder** controls by activating the lock.



1. Slide left

This locks the controls.

2. Slide right

This unlocks the controls.

NOTE

- Landscape mode cannot be used when locked.

Other options

Swapping left and right input channels

iQ series only feature

The left and right channels can be swapped when using an **iQ** series mic. Use this function when the left and right channels of the **iQ** series mic are actually reversed, such as when using the built-in camera of the iOS device to record video.

1. Touch **MENU**

The **MENU** screen opens.

2. Touch L/R SWAP

The L/R SWAP screen opens.

3. Touch ON or OFF

Turn ON to swap the left and right channels of the **iQ** series mic. The default value is OFF. The L/R SWAP setting made with **Handy Recorder** is stored in the **iQ** series mic itself, so the setting will also be applied when using the **iQ** series mic with other apps.

Restoring default settings

You can restore **Handy Recorder** to its default settings.

1. Touch **MENU**

The **MENU** screen opens.

2. Touch **RESET**

A "Reset all Handy Recorder Settings? It cannot be undone!" message appears. Touch **Reset** to restore the default settings, or touch **Cancel** to keep the current settings. When resetting finishes, "Complete!" appears.

System requirements: iOS 6.0 or later

 demco® imagine what's possible™

If you require assistance during assembly, our Customer Service team can help you!
Email custserv@demco.com or call 800.356.1200