

MAXFILE ASSEMBLY DVD MAXFILE ASSEMBLY (MF480, DVD360)

To Assemble:

- 1. Lay 1 side on floor or work surface with cam locks up (use cardboard or padding to avoid scratching or marring).
- 2. Align hardware on back with cam locks in side panel.
- 3. When hardware is aligned, gently insert tabs into cam lock and snug by turning cams clockwise

(DO NOT OVER TIGHTEN)

- 4. Align bottom shelf following steps 2 & 3
- 5. Gently set opposite side panel on raised ends of back top and bottom shelf. Follow steps 2 & 3.
- 6. Stand unit upright, check all cams for snugness
- 7. Align top drawer and fasten with bolts (PACKAGED UNDER MAT).
- 8. Carefully line up and insert drawers.

