



ASSEMBLY INSTRUCTIONS


Remove all items from the carton . Verify all pieces before assembly.

PARTS LIST

KEY	QTY	DESCRIPTION	KEY	QTY	DESCRIPTION	KEY	QTY	DESCRIPTION
1	5	Caster	7	1	Backrest	40	2	Mechanism Bracket Screw 8x20mm + Washer
2	1_	Base	8	2	Armrest	12	3	
3	1	Seat Post	0	2	Arm Width Adjustment	13	1	Backrest Screw 8x10mm
4	1	Seat Post Cover	9		Knob + Washer	14	1	Backrest Post
5	1	Mechanism	10	2	Arm Bracket			
6	1	Seat	11	1	M5 Size Allen Wrench			







raise and lower the back several times after assembling the chair to insure smooth functioning. MECHANISM INSTRUCTIONS (A) SEAT HEIGHT ADJUSTMENT :
Pull lever up and downward Release lever when desired position is reached BACK TILT ADJUSTMENT : Pull lever horizontally. Move backrest to tilt. To lock in upright position. push lever in TILT TENSION ADJUSTMENT KNOB Rotate knob clockwise / counterclockwise to adjust till tension based on body weight

If the up/down operation of the ratchet back feels tight,

PREVENTIVE MAINTENANCE AND WARNING!

- USE THIS PRODUCT ONLY FOR SEATING ONE PERSON AT A TIME DO NOT USE THIS CHAIR AS A STEP STOOL / LADDER DO NOT SIT ON ANY PART OF THE CHAIR EXCEPT THE SEAT DO NOT USE CHAIR ON UNEVEN FLOOR SURFACES DO NOT USE CHAIR UNLESS ALL BOLTS, SCREWS AND KNOBS ARE TICUTENES TIGHTENED
- **EVERY SIX MONTHS, PLEASE MAKE SURE ALL BOLTS, SCREWS AND KNOBS** ARE FULLY TIGHTENED TO ENSURE STABILITY.

- IF ANY PARTS ARE MISSING, BROKEN, DAMAGED OR WORN STOP USE OF THE PRODUCT UNTIL REPAIRS ARE MADE USING FACTORY AUTHORIZED PARTS DISPOSE OF PACKAGING PROPERLY PLASTIC BAG IS NOT A TOY DO NOT USE PLASTIC BAG AS HEAD COVERING IT MAY CAUSE SUFFOCATION FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY NOTE SOME SCREWS MAY BE PREASSEMBLED IF PREASSEMBLED IGNORE **ASSEMBLY INSTRUCTIONS**

Find Eurotech Mesh Back Task Chairs @demco.com, search eurotech mesh back task chair

Call 800.962.4463 or email custserv@demco.com